153S-D26JBD-D40-3-3B-BP

480V
3PH 50Hz/60Hz
L1 L2 L3

CB1
L1 1L1
L2 1L2
L3 1L3

RC L1 T1
L2 T2
L3 T3

OL L1 T1

SMC-50
L1/1 T1/2
L2/3 T2/4
L3/5 T3/6
SMC
SMC POWER TERMINALS (SEE MANUAL)

L1 BLK TB1 L1
L2 BLK TB1 L2

+REMOTE
MTR1
U1
V1
W1
PE
M
3 ~
GRD

SEPARATE CONTROL
4

SMC 1 L
QC LT
QC N
SMC 2

HAND/OFF/AUTO
PLUG E
L 13 14 4
23 24 5

SMC/OFF/BYPASS
S3

BR 11 14
SR 11 14
SR 34 31
SMC 18
SMC 5 *
+REMOTE

SR A1 A2
OL 95 WHT 95 96
SMC A5 96 WHT
QC 6
QC A3
SMC A3
QC 7
BR A1 A2

SR 21 24
R1 A1 A2
BR 21 24
SMC A6 A7
RC A1 RED A1 A2 A2 WHT
SMC A9 A8
QC P1
RC 13 RED 13 14 14 RED
SMC A10 A11
QC F

QC L
QC 8
SMC A4
QC L
R1 11 14
SMC A2

RC 21 RED 21 22 22 RED
SMC 6 7
QC P2

SMC 3
3 GRN MT_PLT
GRD

QC N
SMC A5

NOTES:

* ADD JUMPER FROM TERMINAL BLOCK "18" TO TERMINAL BLOCK "5" WHEN USING DPI (-HC3 or -20*) JUMPER IS INCLUDED IN RAIL IN TERMINAL BLOCK 18.

** REMOVE PRE-INSTALLED YELLOW JUMPER BETWEEN TERMINAL BLOCK "L" AND TERMINAL BLOCK"8" WHEN USING AUX COMMAND DEVICE

1 SMC FACTORY PRE-PROGRAMMED PARAMETERS;
A2=START. A3=COAST. A4=OPTION STOP
Product specific (not test setup ones):
- PAR# 56 Disable 0
- PAR# 57 Disable 0
- PAR# 172 Aux1 Config to Ext Bypass 4
- PAR# 176 Aux2 Config to Fault Normal (0)
- PAR# 177 Enabled (1)
- PAR# 230 (Upper) XXXX XXXX 0000 0010
- PAR# 230 (Lower) 0000 0000 0000 0001

SMC50 I/O device parameters (150-SM4):
- With HIM and Communication Card installed In Port 00 SMC-50
- PAR # 148 X000 0000 0001 0100
- PAR # 3 Input 2 (A2) Start 1
- PAR # 4 Input 3 (A3) Coast 2
- PAR # 5 Input 4 (A4) Stop Option 3
- PAR # 6 Aux1Cfg Ext Bypass 4
- PAR # 10 Aux2Cfg Normal 0
- Set PAR # 14 Aux3Cfg Fault 2

2 RELAY FUNCTIONS;
R1: PREVENT RACE CONDITION BETWEEN A3 & A2
BR 11-14: HOLD-IN CONTACT WITH START-STOP FOR BYPASS
SR 11-14: HOLD-IN CONTACT WITH START-STOP FOR SR RELAY (STARTS SMC)
SR 31-34: STARTS SMC WITH PILOT DEVICE (NO DPI PRESENT)
R1 11-14: SMC START COMMAND

3 USE 75ºC CU WIRE ONLY

4 LINE FUSES SUPPLIED BY CUSTOMER WHEN DISCONNECT SWITCH IS SUPPLIED. REFER TO NEC WHEN SELECTING SHORT CIRCUIT PROTECTION

5 ADDITIONAL CONTROL CIRCUIT OVERCURRENT PROTECTION REQUIRED FOR NON-COMBINATION STARTERS. REFER TO NATIONAL ELECTRIC CODE.

Wire Connector Torque	
Line Terminal (Lb.In.)	Load Terminal (Lb.In.)
220	275

CONFIDENTIAL AND PROPRIETARY INFORMATION:
THIS DOCUMENT CONTAINS CONFIDENTIAL AND PROPRIETARY INFORMATION OF ROCKWELL AUTOMATION, INC., AND MAY NOT BE USED, COPIED OR DISCLOSED TO OTHERS, EXCEPT WITH THE AUTHORIZED WRITTEN PERMISSION OF ROCKWELL AUTOMATION, INC.

Rockwell Automation

Title: SMC COMBO

S.O.

CATALOG NO. 153S-D26JBD-D40-3-3B-BP

Drawn by: AUTO_GEN | **Date:** 02/01/18 | **Sheet:** 1 of 2 | **Ver:** 00 | **Size:** D