

**Step 1: Measure top hole of handle on enclosure**

- Measure hole center to side of enclosure
- Measure hole center to top of enclosure

**Step 2: Lay template on enclosure back plate and align by using the top hole on paper and measurements taken from Step 1**

**Step 3: Tape template down, punch, and drill holes**

