



F1 = 140F-D3; Q11, Q12 = 100-C;
F2 = 193-EC2/EC3

1) Thermistor input (PTC)

2) External ground fault sensor, with 193-EC3 only

Standard Busbar Modules

MCS Reversing Starter
MCS Wendestarter
MCS Démarrage-inverseur
MCS Teleinvertore
MCS Inversore

MASSTAB ECHELLE SCALE	GEZ. Dat. 22.11.12		GEPR.		GES.	
	Name Hug					
	Nr. 0A Dat. 22.11.12 Vis. Hug	Nr. 01 Dat. 28.08.13 Vis. Hug				