


800S RepairParts

NEMA Type 1 Surface Mount Pushbutton Stations



Cat. No. 800S-2SA

Two pushbutton station shown less buttons

Complete Device Shown

(Replacement Pushbutton caps are listed on page 2. Items 5 Cover Screws and Item 6 Cover Washers are not available for sale.)

Catalog Number ①	Description and Legend Markings (Momentary Buttons are used unless otherwise specified)	Item 1 Cover Only less Nameplate	Item 3 Cover Nameplate (with AB logo)
800S-1SA	Stop (N.C. contact)	Not Available	Not Available
800S-1SAK	Stop (N.O. contact)	Not Available	Not Available
800S-1SB	Start (N.O. contact)	Not Available	Not Available
800S-2SA	Start-Stop (N.O. – N.C. contact)	F-21738	Not Available
800S-2SAK	Start-Stop (N.O. – N.O. contact)	F-21738	Not Available
800S-2SAP	Start-Stop w/pilot light ②	F-21738	Not Available
800S-2SB	For-Rev (N.O. – N.O. contact)	F-21738	Not Available
800S-2SF	Open-Close (N.O. – N.O. contact)	F-21738	Not Available
800S-2SE	On-Off (N.O. – N.C. contact)	F-21738	Not Available
800S-2SEK	On-Off (N.O. – N.O. contact)	F-21738	Not Available
800S-2SD	Raise-Lower (N.O. – N.O. contact)	F-21738	Not Available
800S-2SC	Up-Down (N.O. – N.O. contact)	F-21738	Not Available
800S-3SF	Fast-Slow-Stop	F-22279	H-24287
800S-3SA	For-Rev-Stop	F-22279	H-24287
800S-3SD	Open-Close-Stop	F-22279	H-24287
800S-3SB	Raise-Lower-Stop	F-22279	H-24287
800S-3SC	Up-Down-Stop	F-22279	H-24287
800S-R2SX	Off-On selector switch	F-22509	Not Available
800S-R2SXP	Off-On selector switch w/pilot light ②	F-21738	Not Available
800S-R3SX	Hand-Off-Auto selector switch	Not Available	Not Available
800S-R3SXP	Hand-Off-Auto selector switch w/pilot light ②	F-21738	Not Available

① Replacement Contacts and Enclosure Base are not available as repair parts for any of the above catalog numbers.

② Red Lens for the pilot light is available as part number 800S-N90R. Lamp (120V) for the pilot light is available as part number 800S-N60. Pushbutton stations with pilot lights can operate on either 120V or 240V by changing connections inside the switch.

800S RepairParts

NEMA Type 1 Surface Mount Pushbutton Stations

Replacement Pushbutton Caps and Selector Switch Knob for 800S Surface Mount Pushbutton Stations

Catalog Number	Description and Legend Markings	Replacement Button(s) ①
800S-1SA	Stop (N.C. contact)	Not Available
800S-1SAK	Stop (N.O. contact)	Not Available
800S-1SB	Start (N.O. contact)	Not Available
800S-2SA	Start-Stop (N.O. – N.C. contact)	Not Available
800S-2SAK	Start-Stop (N.O. – N.O. contact)	Not Available
800S-2SAP	Start-Stop w/pilot light	Not Available
800S-2SB	For-Rev (N.O. – N.O. contact)	Not Available
800S-2SF	Open-Close (N.O. – N.O. contact)	Not Available
800S-2SE	On-Off (N.O. – N.C. contact)	Not Available
800S-2SEK	On-Off (N.O. – N.O. contact)	Not Available
800S-2SD	Raise-Lower (N.O. – N.O. contact)	Not Available
800S-2SC	Up-Down (N.O. – N.O. contact)	40193-032-06 (up), 40193-032-07 (lower)
800S-3SF	Fast-Slow-Stop (Not Available
800S-3SA	For-Rev-Stop	40193-032-02 (for), 40193-032-03 (rev), (stop is not available)
800S-3SD	Open-Close-Stop	Not Available
800S-3SB	Raise-Lower-Stop	Not Available
800S-3SC	Up-Down-Stop	40193-032-06 (up), 40193-032-07 (lower), (stop button is not available)
800S-R2SX	Off-On selector switch	Not Used ②
800S-R2SXP	Off-On selector switch w/pilot light	Not Used ②
800S-R3SX	Hand-Off-Auto selector switch	Not Used ②
800S-R3SXP	Hand-Off-Auto selector switch w/ pilot light	Not Used ②


① Blank buttons (less engraving) are not available for sale as a replacement repair part numbers. Green button (with no engraving) is not available for sale as a replacement repair part number. Black button (with no engraving) is not available for sale as a replacement repair part number.

② Replacement selector switch knob is not available for sale as replacement repair part number.

800S RepairParts

NEMA Type 1 Flush Mounting Pushbutton Stations with Momentary Pushbuttons (wall box not included)



Flush Mount Units fit a standard GEM or Handy Type Wall Box. Contact Symbol  Cat. No. 800S-2AS

(Cover Plate, Cover Screws and Cover Washers are not available for sale as replacement repair part numbers)

Catalog Number	Contact Block ③	Contact Block Configuration	Pushbutton Assembly ①
800S-2AS	40193-415-54	1 N.O. – 1 N.C.	Z-21835
800S-2ASK	40193-415-52	1 N.O. – 1 N.O.	Z-21835
800S-2ASM ②	40193-415-54	1 N.O. – 1 N.C.	Not Available
800S-2BS	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2BSM ②	40193-415-54	1 N.O. – 1 N.C.	Not Available
800S-2FS	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2ES	40193-415-54	1 N.O. – 1 N.C.	Not Available
800S-2ESK	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2DS	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2CS	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2CSM ②	40193-415-54	1 N.O. – 1 N.C.	Not Available
800S-2ASQ	40193-415-54	1 N.O. – 1 N.C.	Z-21835
800S-2ASKQ	40193-415-52	1 N.O. – 1 N.O.	Z-21835
800S-2BSQ	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2FSQ	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2ESQ	40193-415-54	1 N.O. – 1 N.C.	Not Available
800S-2ESKQ	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2DSQ	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2CSQ	40193-415-52	1 N.O. – 1 N.O.	Not Available

① Pushbutton Assembly includes pushbutton springs, retainers, outside housing, pushbutton caps.

② Pushbuttons are maintained.

③ Part number does not include the mtg bracket or the mtg screws. Order part number X-272778 for mtg bracket and part number M-6717 for mtg screw (qty 2 req'd)

NEMA Type 1 Surface Mounting Pushbutton Stations with Maintained Pushbuttons



Cat. No. 800S-2SCM

(Cover Plate, Cover Screws and Cover Washers are not available for sale as replacement repair part numbers)

Catalog Number	Contact Block	Contact Block Configuration	Pushbutton Assembly
800S-2SAM	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2SAMP ①②	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2SBM	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2SBMP ①②	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2SCM	40193-415-52	1 N.O. – 1 N.O.	Not Available
800S-2SCMP ①②	40193-415-52	1 N.O. – 1 N.O.	Not Available

① Pushbutton station includes one pilot light. Pilot light can be used on either 240V or 120V by changing connections.

② Red Lens for the pilot light is available as part number 800S-N90R. Lamp (120V) for the pilot light is available as part number 800S-N60. Pushbutton stations with pilot lights can operate on either 120V or 240V by changing connections inside the switch.

800S RepairParts

NEMA Type 4 and Type 7 Pushbutton Stations



Double External Operating Lever
shown above for 800S-2SA4



Contact Block



Car. No. 800S-2SA4

Complete device 800S-
2SA4 shown above

Catalog Number	External Operating Lever	Contact Block ③	Contact Block Configuration	Cover Gasket	Cover Assembly w/o Contact Block ①	Legend Plate on Front Cover
800S-1SA4 ②	A-78812	40193-415-54	1 N.C.	F-26198	X-308573	Not Available
800S-1SAK4 ②	A-78812	40193-415-54	1 N.O.	F-26198	X-308573	Not Available
800S-1SB4 ②	A-78812	40193-415-54	1 N.O.	F-26198	X-308573	Not Available
800S-2SA4	A-78811	40193-415-54	1 N.O. – 1 N.C.	F-26198	X-308572	Not Available
800S-2SAK4	A-78811	40193-415-52	1 N.O. – 1 N.O.	F-26198	X-308572	Not Available
800S-2SB4	A-78811	40193-415-52	1 N.O. – 1 N.O.	F-26198	X-308572	Not Available
800S-2SF4	A-78811	40193-415-52	1 N.O. – 1 N.O.	F-26198	X-308572	Not Available
800S-2SE4	A-78811	40193-415-54	1 N.O. – 1 N.C.	F-26198	X-308572	Not Available
800S-2SEK4	A-78811	40193-415-52	1 N.O. – 1 N.O.	F-26198	X-308572	Not Available
800S-2SD4	A-78811	40193-415-52	1 N.O. – 1 N.O.	F-26198	X-308572	Not Available
800S-2SC4	A-78811	40193-415-52	1 N.O. – 1 N.O.	F-26198	X-308572	Not Available
800S-1SA7 ②	Not Available	40193-415-54	1 N.O. – 1 N.C.	Not Used	Not Available	Not Available
800S-1SAK7 ②	Not Available	40193-415-54	1 N.O. – 1 N.C.	Not Used	Not Available	Not Available
800S-1SB7 ②	Not Available	40193-415-54	1 N.O. – 1 N.C.	Not Used	Not Available	Not Available
800S-2SA7	40174-119-02	40193-415-54	1 N.O. – 1 N.C.	Not Used	Not Available	Not Available
800S-2SAK7	40174-119-02	40193-415-52	1 N.O. – 1 N.O.	Not Used	Not Available	Not Available
800S-2SB7	40174-119-02	40193-415-52	1 N.O. – 1 N.O.	Not Used	Not Available	Not Available
800S-2SF7	40174-119-02	40193-415-52	1 N.O. – 1 N.O.	Not Used	Not Available	Not Available
800S-2SE7	40174-119-02	40193-415-54	1 N.O. – 1 N.C.	Not Used	Not Available	Not Available
800S-2SEK7	40174-119-02	40193-415-52	1 N.O. – 1 N.O.	Not Used	Not Available	Not Available
800S-2SD7	40174-119-02	40193-415-52	1 N.O. – 1 N.O.	Not Used	Not Available	Not Available
800S-2SC7	40174-119-02	40193-415-52	1 N.O. – 1 N.O.	Not Used	Not Available	Not Available

① Part number includes four cover screws. Cover screw is available separately as part number 28169-140-26.

② Catalog number uses a single external lever operator.

③ Part number does not include the mtg bracket or the mtg screws. Order part number X-272778 for mtg bracket and part number M-6717 for mtg screw (qty 2 req'd)