



Fuse Holder: 140F-D3..
 Contactor: 100-C09...23
 Motor Protection Relay: 193-EC...

(a) With additional side-mount aux. contact(s)
 (b) Standard busbar adapter
 (c) Iso busbar adapter

FILE: D00GBC-01.DWG

MCS Direct On-line Starter MCS Starter für Direktanlauf MCS Démarreur direct MCS Avviatore diretto MCS Arrancador directo	MASSTAB ECHELLE SCALE	GEZ. Dat. 24.06.08	GEPR. Y	GES.
	Name P. Hug	N	Wa	
	Nr. 01 Dat. 24.06.08 Vis. Hug	Nr. 02 Dat. Vis.		